



Figure 1. Model H6165 Cargo Carrier

### Assembly

1. Arrange the three holes in the receiver mount vertically.
2. Insert the receiver mount under the mesh screen of the bed frame and between the arched bed frame supports as shown in **Figure 1**.
3. Insert two hex bolts through the top of the bed frame and down through the receiver mounting bar. Insert another in the top hole.
4. Attach a hex nut to each of the hex bolts and tighten.

### Model H6165 Assembly Inventory

Receiver Mount .....	1
Bed Frame.....	2
Hex Bolts M10-1.5 x 45 .....	2
Hex Nuts M10-1.5 .....	2

Like all Grizzly products, the Model H6165 Cargo Carrier is covered by a one year warranty. Should any problems arise, please call our customer service center at (570) 546-9663 or e-mail us at [techsupport@grizzly.com](mailto:techsupport@grizzly.com).

## **!WARNING**

1. Never exceed the 500lbs capacity of the cargo carrier, or the maximum tongue weight of your hitch.
2. Always remove the cargo carrier when not in use.
3. Use extra caution when backing up, remember the extra length of your vehicle while cargo carrier is in use.
4. Avoid blocking the rear view visibility with items on the cargo carrier.
5. Load the cargo carrier evenly.

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>