

WAGAN Corp. Limited Warranty Registration Form

All WAGAN Corporation products are warranted to the original purchaser of this product. Warranty Duration: This product is warranted to the original purchaser for a period of one (1) Year from the original purchase date, to be free of defects in material and workmanship. WAGAN Corporation disclaims any liability for consequential damages. In no event will WAGAN Corporation be responsible for any amount of damages beyond the amount paid for the product at retail. In the even of a defective item, please ship the item, prepaid, with a complete explanation of the problem, your name, address and daytime phone number. WAGAN Corporation will, at its option, replaces or repair the defective part. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA and does not extend to any units which have been used in violation of written instructions furnished.

Warranty Disclaimers: This warranty is in-lieu of all warranties expressed or implied and no representative or person is authorized to assume any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to negligence, gross negligence, strict liability, breach of warranty and breach of contract.

Warranty Performance: During the above one (1) Year warranty period, a product with a defect will be replaced with a comparable model when the product is returned to WAGAN Corporation with an original store receipt. The replacement product will be in warranty for the balance of the one (1) Year warranty period.

- Please activate my limited warranty for WAGAN Corp. Easy Quick Jumper
- Enclosed copy of original sales receipt.

Name			
Mail Address			
City			
State, Zip Code			
Item Purchased	Easy Quick Jumper		
Stores Name			
Date of Purchase			
Signature		Date	

All WAGAN Corporation Products must be registered within (30) days of purchased to activate this warranty. Mail the complete registration form, along with a copy of the original receipt to:

Attn: Customer Service
 WAGAN Corporation
 3589 Yale Way
 Fremont, CA 94538

© 2004 WAGAN Corp.



Item no. 9796

Easy Quick JUMPER™



User's Manual

Easy Quick Jumper by Wagan Tech

USER'S MANUAL — Please read before using this equipment.

Thank you for purchasing the Easy Quick Jumper by Wagan Tech. With normal care and proper treatment it will provide years of reliable service. Please read all operating instructions carefully before use.

FEATURES

- Safe, easy and effective.
- Starts a car in 10 minutes.
- Simply connect between the 12V cigarette lighter sockets of two vehicles without the need to open the hoods.
- LED lights illustrate the charging process.
- Designed for 12V vehicles only.
- This system will only function with cigarette lighter sockets with positive center posts.
- Safer than jumper cables.
- Extra long 20 ft. power cord.

SPECIFICATIONS

- Rating: 12V 6A DC
- 20 ft. cord

OPERATING INSTRUCTIONS

1. Make sure the lamps, stereo, air conditioner, and all power using equipment are turned off.
2. Connect the plug with longer blue power cord to the “run-down” vehicle’s cigarette lighter socket.
3. Connect the shorter black power cord to the operating vehicle’s plug.
4. Start the engine of the operating vehicle; the red “charging” LED should turn on.
5. About 10 minutes later when the red LED turns green, start the engine of the “run-down” vehicle.
6. Once the engine of the vehicle with the “run-down” battery starts, remove the plugs from the cigarette lighter sockets on both vehicles and stow the Easy Quick Jumper for future use.
7. Allow the engine on the just-started vehicle to warm up to operating temperature before driving.
8. If the engine of the vehicle being jumped doesn’t start after the second attempt, the battery may have been depleted. Under such conditions a battery replacement would be needed.

TROUBLESHOOTING

1. Remove and reinsert the black plug into the cigarette lighter socket.
2. Restart the engine of the operating vehicle and allow the vehicle to continue to run.
3. Remove and reinsert the blue plug into the vehicle with the “run-down” battery.
4. Switch the ignition lock of this vehicle to the “Accessory” position.
5. This system will only function with cigarette lighter sockets with positive center posts.
6. Wait for 10 minutes or more and try again.
7. Be sure that all accessories on both vehicles are turned off.
8. Remove and reinsert both black and blue plugs.
9. No recharging system will help a battery that is shorted internally or malfunctioning. Under such conditions please replace the battery.

Problems:	Possible Cause:
The green LED power indicator going to the operating vehicle does not illuminate when the plug with the shorter cord is inserted into the cigarette lighter socket.	The black power cord plug is not fully inserted into the cigarette lighter socket of the operating vehicle.
	The engine of the operating vehicle is not running.
The green “power” LED illuminates, but the red “charging” LED panel does not illuminate in sequence.	The “run-down” vehicle’s cigarette lighter socket has a negative center post.
	The blue power cord plug has not been properly inserted into the vehicle with the “run-down” battery.
	The ignition lock of the vehicle with the “run-down” battery is not in the “accessory” position.
The vehicle with the “run-down” battery will not start after 10 minutes.	The “run-down” vehicle’s cigarette lighter socket has a negative center post.
	The battery in this vehicle is fully discharged or shorted internally.
	There is not sufficient electric power in the “run-down” battery to start the engine.
	System plugs are NOT properly inserted in the cigarette lighter sockets.



Simply connect between two vehicles' 12-volt cigarette lighter sockets.

© 2004 Wagan Corporation.
All Rights Reserved.

Wagan and Wagan.com are trademarks used by Wagan Corporation.



Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>