


TOP AND CONSOLE PARTS

29" ELECTRIC DRYER

For Model: NED5240TQ0
(White)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

TOP AND CONSOLE PARTS

For Model: NED5240TQ0

(White)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	5	W10110049	Knob,	15	357213	Nut, Push-In (2)
	W10088970	Installation,			Push-To-Start	16	8557930	Top
		Installation		8271365	White	17	8576500	Harness, Wiring
	W10089173	Sheet,	6	388326	Screw, Console	18	94614	Terminal
		Cycle Feature	7	693995	Screw, Hex Head	19	3977456	Switch,
	W10088771	Use & Care Guide	8	8271359	Cap, End (R.H.)			Push-To-Start
	8576793	Wiring Diagram	9	3395683	Housing, Connector (Motor)	20	W10110048	Timer-Knob
2	8274261	Panel, Rear Console	10	8558463	Screen, Lint	21	8299778	Timer, 60 Hz.
3	3394427	Clip, Harness	11	8536939	Clip, Spring	22	3936144	Connector
4	8271365	Cap, End (L.H.)	12	8533971	Screw, 8-18 x 5/16	24	8271418	Bracket-Control
			13	688983	Screw, 8-18 x 5/8	25	W10086672	Panel-Control
			14	8533951	Screw, Grounding			

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

CABINET PARTS

For Model: NED5240TQ0

(White)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

CABINET PARTS

For Model: NED5240TQ0

(White)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2	343641	Screw, 10-16 x 1/2	16	3392100	Foot, Dryer	26	348780	Base, Motor
3	693995	Screw, Hex Washer Head		279810	Foot - Optional (Extended Length Package Of 2) (Not Included)	27	342055	Screw, 8-18 x 1/2
4	8541400	Bracket, Cabinet	17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 39)	28	3405514	Hinge, Door
5	3396795	Cover, Block				29	691366	Idler & Pulley Assembly
6	3403630	Plug, Strike Hole	18	8530603	Cabinet (Includes Illus. 4)	30	W10131364	Belt, Drive
7	3396805	Panel, Rear				31	8066217	Hinge, Top (2)
8	697776	Screw, 8-32 x 3/8 External Ground				32	3397659	Block Terminal
9	3405246	Seal, Door	19	98234	Clip, Ground	33	3403431	Strike, Door
10	3406109	Door Switch Assembly	20	690363	Lock, Front Top (2)	34	3393008	Screw, 10-16 x 1/2
11	697773	Screw, 6-20 x 7/8	21	3403444	Panel, Front	35	3402341	Door, Rear
12	3404413	Plug, Hinge Hole	22	8066184	Pulley, 60 HZ.	36	3402335	Door, Front
13	3404162	Clamp, Motor (W/Shield)	23	685203	Clip, Felt Pad (3)	37	3405184	Handle, Door
14	660658	Clamp, Motor	24	3389441	Catch, Door Assembly	38	3406129	Seal & Bearing Assembly
15	3394083	Clip, Front Panel (2)	25	3400500	Bolt, 5/16-18 x 3/4	39	279393	Terminal Block Kit (For Terminal Block)
						40	8066206	Motor Assembly 60 HZ.

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

BULKHEAD PARTS

For Model: NED5240TQ0

(White)



Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	489463	Screw, 8-18 x 5/8
3	3388703	Washer-Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8-18 x 3/8
6	696302	Shield, Exhaust
7	3392519	Thermal Fuse
8	3387134	Thermostat, Internal-Bias
9	3977393	Thermal Cut-Off (Includes Illus. 15)
10	694089	Wheel, Blower
11	8577230	Housing, Blower

Illus. No.	Part No.	DESCRIPTION
12	8066155	Clip
13	343641	Screw, 10-16 x 1/2
14	8541818	Box, Heater
15	3977767	Thermostat, 221°F (105°C)
16	3403636	Baffle-Drum (1)
17	3403585	Element, Heater
18	339956	Seal
19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)
20	8066086	Drum Hole Plug
21	3390647	Screw, 8-18 x 1/2

Illus. No.	Part No.	DESCRIPTION
22	690997	Ring, Tri
23	3399506	Shaft, L.H.
24	3399507	Shaft, R.H.
25	3397590	Roller, Support
26	348197	Washer, Support
27	3359452	Nut, 3/8-16
28	3403491	Bulkhead
29	692526	Ring, Bearing
30	W10109200	Screw, 11-16 x 3/4
31	3406130	Seal, Rear Drum
32	695587	Drum Assembly
33	692490	Baffle, Drum (2)
34	3976434	Bracket, Support
35	90296	Clip

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

OPTIONAL PARTS (NOT INCLUDED)

For Model: NED5240TQ0

(White)

Illus.	Part	
No.	No.	DESCRIPTION

ACCESSORY PARTS

279948	Kit, Dryer Repair
3404351	Dry Rack
8522199	Kit, Dryer Vent Testing

PAINT, TOUCH-UP (1/2oz.)

72017	White
4392899	Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
350938	Primer, Gray

PAINT, BULK (1 qt.)

799344	White (Uncut)
--------	---------------

IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>