
Flash-1C™



Caution! Always disconnect from main power before servicing unit. Remember to always replace with same fuses.

Model: **Flash-1C™**

SPECIFICATIONS:

Power: 110V/60Hz

Weight: 3 lbs.

Size: 11.25" x 5.25" x 3"

Fuse: 10A

Thank you for purchasing this American DJ® product. For your convenience this products ready to be used, there is no assembly required. Please read the following instructions before installing or using your new unit.

Operating Instructions:

The American DJ® Flash-1C, flash tube controller is ideal for mobile DJ's and club use. One Flash-1C will control up to 20 Flash Tubes. The Flash Tubes can be controlled in two ways AUTO or MANUAL (blue button). When switch is on MANUAL , the user has control of the SPEED and and MODE knobs . Only by pushing the yellow TRIGGER button, will the Flash Tubes light. When switch is on AUTO, the user has control of SPEED, MODE, and pulse RATE knobs.

SPEED knob - Controls speed of chase.

MODE knob - Coose 1 of 5 mode to chase in.

1. Forward
2. Reverse
3. Crossover
4. Rebound
5. Auto chase

RATE knob - Controls rate of pulse (ie. speed of strobe) of the Flash Tubes.

For service, contact your American DJ® dealer.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>