



*ELITE Series*TM

PORTABLE GENERATORS

Illustrated Parts List

Questions? Help is just a moment away!
Preguntas? La ayuda es justa un momento lejos!

Call: **Generator Helpline**

Llame: **Línea Directa del Generador**

1-800-743-4115 M-F 8-5 CT

web: www.briggsandstratton.com


030386 (6200W)



BRIGGS & STRATTON POWER PRODUCTS GROUP, LLC
JEFFERSON, WISCONSIN, U.S.A.

Manual No. 197523A Revision - (12/19/2007)

EXPLODED VIEW - MAIN UNIT




Copyright © 2007 Briggs & Stratton Power Products Group, LLC. All rights reserved. No part of this material may be reproduced or transmitted in any form by any means without the express written permission of Briggs & Stratton Power Products Group, LLC.

EXPLODED VIEW - PARTS LIST

Item	Part #	Description	Item	Part #	Description
1	M197464GS	KIT, Cradle (Includes Items 20, 31 & 55)	45	B4363GS	CAP, Fuel Gauge
2	194150GS	KIT, Vibration Mount, 45°	46	B4135GS	PIN, with Lanyard
3	*	NUT, M8 Flange Serrated	47	77395GS	NUT, M6 Flange Lock
4	190220GS	HOUSING, Engine Adapter	48	195373GS	WIRE, Ground
5	*	NUT, Hex, M8-1.25	49	*	WASHER, M6 Shakeproof
6	NSP (194080)	ASSY, Alternator	50	188333GS	DECAL, Instruction, Fuel Level
7	*	TPHMS, M8-1.25 x 35	51	194799GS	DECAL, Danger
8	96796GS	WASHER, 8.4 x 22.2 x 3	52	189235GS	DECAL, Start Instructions
10	190274DGS	SBHCS, 3/8-16 x 7/8"	53	194034GS	KIT, Handle Fold-down Hardware
11	187365FGS	HHCS, 5/16-24 x 7.44	54	194448GS	KIT, Insulation with Clip
12	*	HHCS, M8 - 1.25 x 25	55	197798GS	DECAL, Fuel Shut-off
14	189009GS	BRACKET, Muffler	56	202997GS	DECAL, Warning CO
15	695398	GASKET, Exhaust	58	191757GS	ASSY, Control Panel
16	*	HHCS, M6-1.0 x 12	59	*	NUT, Palnut, 3/16"
17	189008GS	MUFFLER	60	194389GS	SHIELD, Heat
18	204885GS	SHCS, M8 - 1.25 x 20	68	195680GS	TRAY, Battery
19	83083GS	SCREEN, Spark Arrest	69	193043GS	BATTERY, 12V
20	B4986GS	DECAL, Ground	70	*	HHCS, M6 - 1.0 x 12
21	194153GS	KIT, Vibration, Mount	71	192531GS	ASM, Jack, DC
22	86494GS	SCREW, Wing M6 - 1.0 x 16	73	58359GS	LUG, 5/16 #22/18 I-S
24	194390GS	SHIELD, Heat	74	193347GS	KIT, Battery Hardware
25	191190GS	CAP	76	185939KGS	WIRE ASM, #55
26	74908GS	TAPTITE, M5-0.8 x 10	78	189302CGS	WIRE ASM, #13
27	*	HHCS, 1/4 - 20 x 3/4	81	189302GGS	WIRE ASM, #16
28	*	WASHER, 1/4, Lock	90	198669GS	GRIP, Handle
29	*	NUT, 1/4 - 20	91	B193200GS	ASSY, Handle/Grip
30	*	WASHER, Shakeproof, Ext. #10	900	§	ENGINE
31	196830GS	DECAL, Hot Muffler	Parts Not Illustrated		
32	*	NUT, 5/16 - 24	MS3430		MANUAL, Engine, B&S
33	*	WASHER, 5/16 - M8 Lock	197523GS		MANUAL, Operator's
34	195422GS	COVER, RBC, Plastic w/Cap	BB3061GS		BOTTLE, Oil
35	791745	KIT, Fuel Hose (cut to fit)	43438GS		PLUG, 250V, 30A
37	B2153GS	SCREW, 12-14 x 7/8 Self Drill	202180GS		DECAL, Family, CA EVP
38	56893GS	SCREW, 10-24 x 1/2 Crimptite	B4177GS		CHARGER, Battery
39	188987GS	BRACKET, Switch	197787GS		KIT, Decals Service
40	195477GS	KIT, Hardware Tank Fuel (Includes Qty 4)			
41	192980GS	KIT, Valve, Tank	* - Items without part numbers are common fasteners and are available at your local hardware store.		
43	77282GS	SWITCH, Starter	§ - Contact Engine Manufacturer		
44	194217GS	ASSY., Tank, Fuel (Includes Items 41, 50, 51, 52 & 56)			


EXPLODED VIEW AND PARTS LIST - CONTROL PANEL



Item	Part #	Description
1	195112GS	KIT, Control Panel Lid
2	191450GS	CONTROL PANEL, Compact
6	68759GS	OUTLET, 120V, 20Amp, Duplex
7	*	NUT, Palnut, 5/32
8	84198GS	CAP, Circuit Breaker
9	75207AGS	CIRCUIT BREAKER, 30A
10	43437GS	OUTLET, 120/240 Locking, 30A
11	*	NUT, Palnut, 3/16
12	*	PPPHS, M3- 0.5 x 18
13	93857GS	BAR, Retaining
14	188890GS	COVER, Back, Control Panel
15	82308GS	SCREW, Tapping, STC 3 x 18
16	22694GS	HOUSING, Receptacle
17	192241GS	SCREW, Tapping, 3.5 x 14
18	75207PGS	CIRCUIT BREAKER, 25A


* - Items without part numbers are common fasteners and are available at your local hardware store.

EXPLODED VIEW AND PARTS LIST - ALTERNATOR



Item	Part #	Description
1	186059GS	ADAPTER, Mounting, Alternator
2	191876GS	ROTOR
3	194006AGS	STATOR
4	186060GS	RBC, (with O-Ring, p/n 189197GS)
5	86308HGS	HHCS, M6 - 1.0 x 140 SEMS
6	66386GS	ASSEMBLY, Holder, Brush
7	66849GS	TAPTITE, M5 - 0.8 x 16
8	22694GS	RECEPTACLE, 6 pin
9	81917GS	PIN, Roll, 4mm x 10
10	193428AGS	WIRE-A, Ground
11	189769GS	REGULATOR, Voltage, AVR
12	194274GS	HARNESS, Wire, Power
13	65791GS	BEARING

EXPLODED VIEW AND PARTS LIST - WHEEL KIT



Item	Part #	Description
1	196517GS	WHEEL, 10"
2	191265GS	E-RING, 5/8
3	191267GGS	AXLE, 5/8" x 23.62"
4	*	WASHER, 5/8
5	*	HHCS, M8 - 1.25 x 20
6	B187101GS	LEG, Support
7	87841GS	VIBE MOUNT
8	*	HHCS, 1/4 - 20 x 1
9	52858GS	NUT, M8 - 1.25 Lock
10	192432GS	NUT, 1/4 - 20 Serrated Lock

Parts Not Illustrated

187046GS SUBKIT, Hardware

* - Items without part numbers are common fasteners and are available at your local hardware store.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>