





## SkipDr Manual

### Quick Start Guide



### **SPRAY**

SkipDr® Rejuvenating Fluid lightly onto the play-side of the disc (do not spray on the label-side).



### **REPAIR**

the disc by inserting it into the SkipDr® Disc Repair System with play-side toward the FlexiWheel™. Turn the crank handle clockwise until the disc completes two full rotations. The disc will move at a much slower rate than the crank handle. Repeat as necessary.



### **DRY + SHINE**

Dry the play side of the disc with the blue drying cloth. Then place the disc on top of the drying cloth and buff using the white buffing square. NOTE: Thorough buffing is crucial for perfect playback. It is normal for a slight, harmless radial pattern to remain on the disc after buffing. Repeat step as necessary. The Flexiwheel™ will repair up to 25 discs.

**WARNING: Not for use with Blu-ray™ or Playstation® 3 discs.**

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>